




HP LaserJet 1160 or 1320 Duplexer Tray Replacement

Replace the duplexer tray of an HP LaserJet 1160 or 1320 printer.

Written By: jrw01





TOOLS:

- [Metal Spudger Set](#) (1)
- [Phillips #0 Screwdriver](#) (1)



PARTS:

- [HP LaserJet 1160 or 1320 Duplexer Tray](#) (1)

Step 1 — Left Side Cover




- Pull on the two tabs on the back of the printer to release the left side cover.
- Remove the cover by rotating it towards the front of the printer.

Step 2 — Right Side Cover




- With the printer turned so that the right side is facing upwards, use a metal spudger to disengage 3 tabs holding the right side cover in place.
- Lift the cover off of the printer.

Step 3 — Back Cover



- Remove 4 screws on the back of the printer.
- Remove the back cover.

Step 4 — Duplexer Tray



- Pull on the blue-green tab to release the duplexer tray.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 10:56:42 AM.